Use and Care Guide

This product is designed to require minimal maintenance. Do not use harsh chemicals or solvents to clean your lock.

Mechanical lock

Use a damp cloth to wipe away any excess dirt or debris.

Electronic lock

Use a damp cloth on the lock's exterior to wipe away any excess dirt or debris. Use a dry cloth to clean interior components.

Copyright © 2012 Stanley Black & Decker Corporation