

Installation Instructions *continued* . . .

Step 5: Installing the Valve Assembly

NOTE: Flush supply lines before making connections.

1. For overhead supply lines, install 1/2" nominal copper supply tubing by passing the lines through the holes in the dispenser cover and then down through the support tube.
2. Install the valving assembly using suitable fittings to the supplies as shown in Figure 7 at the approximate height indicated in Table 2.
3. Slide the tailpiece nut over the tailpiece and connect the tailpiece to the supply pipe (or to the nipple/coupling for B or H drain).




Table 2 — Distance from 1/2" Supply to Finished Floor

Model Number	Type A	Type B	Type O	Type H
Standard Height	9" (229mm)	6-3/16" (157mm)	9" (229mm)	6-3/16" (157mm)
Juvenile Height	5-1/4" (133mm)	3-7/16" (87mm)	5-1/4" (133mm)	3-7/16" (87mm)